Retro Portable Wireless Speaker Instructions

Specifications

Bluetooth V5.0+EDR
Bluetooth range 10m
USB power input DC 5V/1A

Battery 3.7V, 500mAh
Playtime 2-4hrs
Charge time 2-4hrs
Speaker output 5W

Charging

Connect charging cable from the micro-USB port to an appropriate USB power source.
LED indicator will glow red when charging and turn off/go dark when fully charged. Disconnect from power when fully charged ro avoid overcharging.
Charging takes 2-4 hours.

Bluetooth pairing

Long-Press the center power/play button for 3-4 secons to power on the speaker and put it into pairing. The light stays on while Bluetooth is connected. If the speaker was previously paired with another device in range, remove/delete the speaker from the other device to break the connection and pair it with the new device.

Power/Play/Pause Button Function

Power on/off, Long-press, 3-4sec
Play/Pause, short press.
Mode switch, double press: FM, Bluetooth, TF, USB, Aux
Call receive, short press when ringing to answer
Call refuse, double press when ringing

FM Radio Operation

Plug in charging cable first. The charging cable acts as the antenna. It does not have to be powered.
Double-Press **Power** for FM mode.
Press **Power** for FM search, press again to stop search. After the search, it will automatically set to the first station found.
Use the previous **<<** and next **>>** buttons to move between stations.

AUX in

Inserting a cable into the AUX port *when the speaker is powered on* will put the speaker into AUX mode automatically. Or double-press power to cycle through modes: FM, Bluetooth, TF, USB, Aux.

TF/micro-SD card reader

Inserting a card into the TF slot *while the speaker is powered on* will put the speaker into TF/SD card mode. Or double-press power to cycle through modes: FM, Bluetooth, TF, USB, Aux.
Use the previous **<<** and next **>>** buttons to move between tracks.

Disclaimer: This speaker is manufactured genetically and sold under many brands and models.

Brands *this is a partial list* : Bass, Aresrora, Nelbonds, Artis, Queqimu, Prunus, Konghyp, Daomix, Springflora, Lukader, Baolira

Models *this is a partial list* : BS-52D, BT12, Retro, J-999, HM11, DW21

The above instructions may not exactly fit yours. We lost our user manual so we didn't have the instructions for all of the buttons and features. I grabbed frames from a YouTube unboxing and transcribed the relevant sections below, clarifying where necessary for instructions without images.